## H31 - RS232 Command List

## Interface

Hardware: 3 wires RS-232C
Baud Rate: 9600
Data Bits: 8
Parity: None
Stop Bits: 1 Flow Control: None

Command Sequence

Write	Basic Protocol		
Header:	·*,		
Address Code:	'0' fixed		
Command Code:	ASCII Text		
Data:	Fixed 3 digits		
Terminator Code:	Code: Carriage Return		

## Command Sequence

Read	Basic Protocol	
Header	·* <sup>,</sup>	
Address Code	'0' fixed	
Command Code	ASCII Text	
Data	"?" fixed	
Terminator Code	Carriage Return	

Acknowledgement

Basic Protocol	Return Status	
Receive OK	Receive OK	
Invalid Command	Invalid Command	
ransmit OK Transmit Ok		
Data response	esponse As Write Command	

## Function List I (IR)

Function	Command
Power On (*1)	OKOKOKOKOK
Power Off	* 0 IR 002
Freeze	* 0 IR 007
Menu	* 0 IR 008
Up	* 0 IR 009
Down	* 0 IR 010
Right	* 0 IR 011
Left	* 0 IR 012
Enter	* 0 IR 013
Re-Sync	* 0 IR 014

Function List II (Directly OSD Menu)

Function	Command
Brightness	* 0 IR 025
Contrast	* 0 IR 026
Color	* 0 IR 029
Mode	* 0 IR 032
Color Temperature	* 0 IR 036
Edge Mask	* 0 IR 037
Brightness	* 0 IR 038
Keystone	* 0 IR 039
FullScreenMode	* 0 IR 043
ImageMode	* 0 IR 044
Phase	* 0 IR 056

Function List III(Auto Status)

Function	Basic Command	
Call Picture state	* 0 AUTO 001	
Exit to Normal state	* 0 AUTO 002	
Save current value as default	* 0 AUTO 003	

Function List IV (Lamp Status)

function	Basic Command	Return Status
Get Lamp Status	* 0 Lamp ?	Lamp 0 (Lamp
		Lamp 1 (Lamp

<sup>\*1:</sup> only MP Product workable